


## Installazione modem Modem Installation

Modem 4G per boss/boss-mini  
Modem 4G per boss/boss-mini



→ LEGGI E CONSERVA  
QUESTE ISTRUZIONI  
← READ AND SAVE  
THESE INSTRUCTIONS ←

ITA Foglio istruzione  
ENG Technica leaflet



# 1. INSTALLING THE MODEM

## 1.1 How to connect and configure the modem


### Prerequisites:

1. Administrator credentials to access system administration
2. Modem kit part number BMHST4GA00
3. Boss or boss-mini with software version >= 1.9.0
4. SIM unlocked (PIN request disabled, if enabled SMS messages cannot be sent)
5. Information for SIM data connection (given by the service provider)
  - User
  - Password
  - APN
  - PIN

**VERY IMPORTANT:** if the boss or boss-mini is rebooted without a modem connected, the modem settings will be lost and the installation procedure will need to be repeated.


### Procedure

1. To install the SIM card and set up data network operation, see the manual (MTCM2 Quick Start).
2. Use the USB extension cable to connect the modem to the boss/boss-mini.
3. Switch the boss/boss-mini on:
  - When the device has started, check the LEDs with reference to the manual (MTCM2 Quick Start). Normal operation is shown in the picture.




4. Open the browser and enter the address <https://unit name:8443/> (e.g. <https://boss-12aa8443/>) and log in as the administrator (important, only the administrator can install the modem)

A



B

Under System administration, select Power from the menu



C

Click Reboot to reboot the unit



D


Warning: once the modem is physically connected to the boss/boss-mini it, it must not be disconnected, otherwise the configuration will be permanently lost.

E


Wait for the System administration login page to be displayed

F


Log in as the administrator (only the administrator can configure the modem)




G From the menu, select Network config - Modem tab



H The page shows the modem information IMSI:..., IMEI:...




J After entering the data connection details and the PIN (if enabled), the screen will be as follows




Depending on the SIM provider, it may be sufficient to enter the APN only

I Complete the fields: User, Password, APN, PIN, following the instructions given by the SIM provider. For example, APN=yourapn.example.



K Click Connect to save the configuration and activate the modem data connection.




L At the top right, "Connecting," will be shown for a few seconds:



M Then "Connected!" will be shown for a few seconds.



N Click the Network config menu item and then the Network tab




In the 4G row the IP address returned by the mode is displayed; if it is not shown, refresh the page.

O The modem has been configured correctly, the data connection is working and is ready to be used.

## 2. UNINSTALLING THE MODEM

1. Switch the boss/boss-mini on
2. Delete the entire SMS configuration from the application.
3. In the browser, enter `https://(unit name):8443/` (e.g. `https://boss-12aa8443/`) and log in as the administrator


A.



B From System administration, select Network config and then the Modem tab

↳ boss supervisory application

C Click Disconnect to disable the data connection



E "Disconnect" will be shown for a few seconds



F Physically disconnect the modem from the boss/boss-mini

G Reboot the boss/boss-mini with the modem disconnected

### 2.2 Remarks

**VERY IMPORTANT:** If the boss or boss-mini is rebooted without a modem connected, the modem settings will be lost and the installation procedure will need to be repeated. This is described in the paragraph: **INSTALLING THE MODEM**

If the PC that is browsing the boss pages is in a different subnet from the boss unit, when the modem is connected, the default gateway is replaced and therefore the pages cannot be browsed: a new route will need to be added in boss before connecting and configuring the modem.


### 2.3 What happens when the modem is disconnected?

As a general rule, every operation performed on the modem requires the boss/boss-mini to be rebooted before taking effect.

Connect or disconnect the modem depending on the desired configuration, then reboot the unit to make the changes and hardware detection effective and complete.


### 3. TROUBLESHOOTING

1. **System administration:** the modem is connected to the boss/boss-mini but 4G Down is shown on the Network page



- Check the operation of the modem with reference to the LEDs (see the quick guide).
- If the LEDs indicate that the modem is working correctly, reconfigure the modem under System administration: follow the modem installation procedure.

2. **Modem physically connected to the boss but the 4G row is not shown in System administration**



- Check the operation of the modem with reference to the LEDs (see the quick guide).
- If the LEDs indicate that the modem is working correctly, reconfigure the modem under System administration: follow the modem installation procedure.